KARCHER

WD 3-18

The battery-operated WD 3-18 wet and dry vacuum cleaner with 18 V battery offers maximum flexibility thanks to its 17-litre plastic container, 2-metre suction hose, blower function and single-part cartridge filter.









Order no.

1.628-550.0

- 17 I stainless steel container, blower function, hose storage and accessory storage
- 18 V battery platform, 2 m hose
- Floor nozzle, crevice nozzle, cartridge filter, fleece filter bag

Technical data		
EAN code		4054278943572
Battery powered device		1
Battery platform		18 V battery platform
Rated input power	W	270
Suction Power	W	75
Vacuum	mbar	max. 110
Air flow	I/s	max. 30
Container capacity	1	17
Container material		Plastic
Colour component		Device head Yellow / Container Yellow / Device bumper Yellow
Nominal size of accessory	mm	35
·		Lithium-ion exchangeable battery
Voltage	V	18
Run time per battery charge	min	approx. 10 (2.5 Ah) / approx. 20 (5.0 Ah)
Sound pressure level	dB(A)	70
Colour		Yellow
Weight without accessories	kg	4.1
Weight incl. packaging	kg	5.8
Dimensions (L × W × H)	mm	349 × 328 × 492

-		
Equipment		
Versions		Battery and battery charger not included
Suction hose length	m	2
Suction hose type		with curved handle
Suction hose material		Plastic
Removable handle		
Quantity of suction tubes	Piece(s)	2
Suction tubes length	m	0.5
Suction tubes nominal width	mm	35
Suction tubes material		Plastic
Wet and dry floor nozzle		clips
Cartridge filter		one-piece
Crevice nozzle		•
Fleece filter bag	Piece(s)	1
Blower function		
Parking position		
Folding carrying handle		
Intermediate parking position of the handle on the device head		
Hose storage on the device head		
Additional accessory storage on		
the device head		_
Accessory storage on the device		•
Sturdy bumper		•
Castors without brake	Piece(s)	4





18 V Kärcher Battery Power exchangeable battery

- Makes it possible to work without the need for a power supply and therefore achieve maximum freedom of movement.
- Real Time Technology with LCD battery display: remaining running time, remaining charging time and battery capacity.
- Compatible with all devices in the 18 V Kärcher Battery Power platform.



Cartridge filter

- For wet and dry vacuuming without filter replacement.
- Simple installation and removal of filter by turning without additional locking part.



Practical accessory storage

- Space-saving, secure and easily accessible accessories storage.
- Compact device storage.

KARCHER

ACCESSORIES FOR WD 3-18 1.628-550.0





























		Order no.	Description	
VACUUMS		Order no.	DESCRIPTION .	H
Filters				_
One-piece cartridge filter KFI 3310	1	2.863-303.0	Cartridge filter for vacuuming fine and coarse dirt and liquids without having to change the filter. Suitable for Kärcher Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	ľ
Fleece filter bags KFI 357	2	2.863-314.0	The extremely tear-resistant KFI 357 fleece filter bags easily cope with vacuuming dry and damp dirt. Suitable for Kärcher Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	
Nozzles	•			
Switchable wet and dry floor nozzle with integrated parking nib	3	2.863-000.0	Switchable wet and dry vacuum nozzle for perfect dirt intake. Easy adaptation to wet or dry dirt using foot switch. For all Kärcher Home & Garden wet and dry vacuum cleaners.	
Car nozzle	4	2.863-316.0	Fast, effortless vacuuming guaranteed: With the car nozzle, you can clean textile surfaces in your car and around the house conveniently and thoroughly.	
Extra-long crevice nozzle	5	2.863-306.0	Completely overhauled extra-long crevice nozzle. Ideal for hard-to-reach places in the car (e.g. gaps and crevices/joints). Suitable for all Kärcher Home & Garden wet and dry vacuum cleaners.	; [
Flexible crevice nozzle	6	2.863-374.0	Flexible crevice nozzle for cleaning hard-to-reach areas in the home, basement, workshop, car, etc. with Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	
Upholstery nozzle	7	2.863-398.0	For gently removing dirt from textile surfaces in the car and household. Suitable for wet and dry vacuum cleaners and spray extraction cleaners.	
Upholstery nozzle for pet hair	8	2.863-375.0	Extra wide upholstery nozzle for reliably removing dirt, especially animal hair, from car and home textiles with Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	
Accessory kits		<u> </u>		
Car interior cleaning kit	9	2.863-304.0	From the footwell and the seats to the car boot: the special accessory kit for Kärcher Home & Garden wet and dry vacuum cleaners ensures uninterrupted interior car cleaning.	
Suction brush kit	10	2.863-221.0	The suction brush kit enables thorough interior car cleaning of dashboards, foot mats, upholstered surfaces, etc., and is suitable for use on all materials. For all Home & Garden wet and dry vacuum cleaners.	
Household kit	11	2.863-356.0	Handy accessory kit for switching between dry floor nozzle and upholstery nozzle. Suitable for all Kärcher Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.	
Blower adapter kit	12	2.863-373.0	Ensures effortless inflation and deflation of air mattresses, swimming pools, inflatable boats, etc. using a Kärcher Home & Garden wet and dry vacuum cleaner.	
Vacuum kit for power tools	13	2.863-112.0	Flexible suction hose (1 m) including adapter for connection to the exhaust air vent of power tools (e.g. jigsaws, grinders, drills, planes, etc.), for dirt-free DIY.	
Special applications				'n
Drill dust catcher	14	2.863-234.0	The new accessory for our WD 2-6 wet and dry vacuum cleaners enables safe and dust-free drilling on all common wall and ceiling surfaces. Drill dust is suctioned directly from the drill hole.	

 $[\]blacksquare$ Included in the scope of supply. \square Available accessories. O Detergents.



ACCESSORIES FOR WD 3-18 1.628-550.0















		1		_
		Order no.	Description	
VACUUMS				
Special applications				
Extension suction tube	15	2.863-308.0	Practical extension suction tube for greater operating range. The extension of the suction tube is recommended particularly for applications in areas that are difficult to access, such as high ceilings	. [
BATTERIES				
Battery Power 18/25	16	2.445-034.0	$18\ V\ /\ 2.5\ Ah$ Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	
Battery Power 18/50	17	2.445-035.0	$18\ V\ /\ 5.0\ Ah$ Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	
BATTERY CHARGERS				
Fast Charger Battery Power 18 V	18	2.445-032.0	The fast charger charges the 18 V/2.5 Ah Kärcher Battery Power exchangeable battery to 80% in just 44 minutes and can be used for all batteries on the 18 V Kärcher battery platform.	
STARTERKIT BATTERIES AND BATTERY CHAR	GERS			
Starter kit Battery Power 18/25	19	2.445-062.0	Battery Power 18/25 Starter Kit incl. 18 V/2.5 Ah Battery Power exchangeable battery with innovative Real Time Technology and 18 V fast charger. For all devices on the 18 V Kärcher battery platform.	
Starter kit Battery Power 18/50	20	2.445-063.0	Incl. 18 V / 5.0 Ah Kärcher Battery Power exchangeable battery and 18 V fast charger: The Battery Power 18/50 Starter Kit for use in all devices on the Kärcher 18 V battery platform.	
BATTERIES				
Battery Power+ 18/30	21	2.445-042.0	With Real Time Technology displayed on an LCD screen: very powerful Battery Power+ 18-volt lithium-ion battery. Long runtime thanks to a capacity of 3.0 Ah. With voltage monitoring and IPX5 protection.	

 $[\]hfill\square$ Available accessories. O Detergents.