

WASH BRUSH

Wash brush with soft bristles for cleaning sensitive areas and areas which are difficult to access in the outside area. Suitable for all Kärcher K 2 to K 7 pressure washers.



Order no. 6.903-276.0

Technical data

EAN code		4002667004564
Colour		black
Weight	kg	0.2
Weight incl. packaging	kg	0.2
Dimensions (L × W × H)	mm	333 × 82 × 164



Extra soft bristles

- Enables cleaning of sensitive areas

COMPATIBLE MACHINES

- K 1 Entry *MX
- K 2
- K 2 Basic *MX
- K 2 Battery
- K 2 Classic
- K 2 Classic Home
- K 2 Horizontal
- K 2 Horizontal *MX
- K 2 Power Control
- K 2 Power Control Car
- K 2 Power Control Home
- K 2 Premium
- K 2 Premium Home
- K 2 Premium Horizontal
- K 2 Premium Power Control
- K 2 Premium Power Control Home
- K 2 Premium VPS
- K 2 Universal Edition
- K 2 Universal Edition Home
- K 2 Universal Edition OJ
- K 2 Universal Edition Promo
- K 2.105
- K 3
- K 3 *GB
- K 3 Car
- K 3 Classic
- K 3 Classic Home
- K 3 Follow Me
- K 3 HR Plus
- K 3 Home
- K 3 Horizontal
- K 3 Horizontal Plus
- K 3 Horizontal Plus Home
- K 3 Induction
- K 3 Power Control
- K 3 Power Control Car
- K 3 Power Control Car & Home
- K 3 Power Control Deck
- K 3 Power Control Home
- K 3 Power Control Home & Pipe
- K 3 Power Control Home T 5
- K 3 Premium
- K 3 Premium Power Control
- K 3 Premium Power Control Car & Home
- K 3 Premium Power Control Home
- K 4
- K 4 Classic
- K 4 Classic Car
- K 4 Classic Home
- K 4 Power Control
- K 4 Premium
- K 4 Premium Silent Veranda 60Hz
- K 5 Classic
- K 5 Classic Car & Home
- K 5 Classic Home
- K 5 Modular UM
- K 5 Power Control
- K 5 Premium Power Control Home
- K 5 WCM Premium
- K 7 Premium Smart Control
- K Mini
- K Mini Plus
- K2 Basic Black *AR
- K2 Basic Black *MX
- K2 Basic Black *PE
- K2 Car Black *AR
- K2 Car Black *MX
- K2 Car&Garden *AR
- K2 Car&Garden *MX
- K2 Dakar *MX
- K2 Follow Me Cordless
- K 3 Power Control
- K 3 Power Control Car
- K 3 Power Control Car & Home
- K 3 Power Control Car & Home
- K 3 Premium Power Control Car & Home
- K 3 Car
- K 3 Car & Home
- K 3 Car & Home
- K 3 Classic Car
- K 3 Classic Car & Home
- K 3 Classic Car & Home
- K 2 Universal Edition Car
- K 2 Power Control Car
- K 2 Power Control Car
- K 2 Power Control Car & Home
- K 2 Power Control Car & Home
- K 2 Power Control Car
- K 2 Universal Edition Car
- K 2 Universal Edition Car
- K 2 Premium Car
- K 2 Classic Car & Home
- K 2 Classic Car
- K 1 Car

ACCESSORIES FOR WASH BRUSH
6.903-276.0



		Order no.	Description	
BRUSHES				
Garden hose adapter	1	2.640-732.0	Adapter for garden hose connection - suitable for attaching all Kärcher brushes to garden hoses with the quick-coupling system.	<input type="checkbox"/>

☐ Available accessories. ☐ Detergents.